



## Sea-R.O. “Nautilus” Quick Reference

### To Start

1. Loosen High Pressure Regulator Valve all the way counter clockwise.
2. Open Product Sample Valve
3. Turn on main breaker
4. Start Boost Pump.
5. Observe Brine Flowmeter for flow and wait until free of air bubbles.
6. Start High Pressure Pump
7. Slowly turn High Pressure Regulator Valve clockwise while observing High Pressure Gauge. Pressure should be adjusted to 800 psi.
8. Product water will begin to flow out of Product Water Sample Valve. Test sample after 1-2 minutes and if results are less than 500 parts per million, close Product Water Sample valve to divert water to storage tank.

### To Shut Down

1. Loosen High Pressure Regulator Valve all the way counter clockwise
2. Turn off High Pressure Pump.
3. Turn off Boost Pump.